



BLU Studio 5.5 Battery Replacement

This guide will detail how to remove and replace the battery for the BLU Studio 5.5.

Written By: Alec Coleman



INTRODUCTION

The battery for the BLU Studio 5.5 is the first component that should be removed before working on replacement for any other components. A common troubleshooting procedure to reset a mobile device follows these same steps; removing the back panel, the battery, reassembling, and powering the device back on.



TOOLS:

- [iFixit Opening Tools](#) (1)

Not essential, but may be easier than opening device by hand

Step 1 — Battery



- Locate the notch to remove the back panel at the lower left corner of the panel.
- Insert the plastic opening tool or a fingernail into the notch.
- Apply force upwards until back panel becomes loosened.

Step 2



- Remove the loosened back panel and set aside.
- Locate the notch to remove the battery.

Step 3



- Insert a plastic opening tool or your fingernail into the notch and apply force upwards until the battery is loosened.
- Remove the battery and set aside.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-18 04:40:44 AM.